

GriP AntiSlip Bathroom

AntiSlip Safety Application

Technical Infosheet – and Application Manual

GriP Safety Coatings AG

Industriestrasse 13
CH-6343 Rotkreuz

Tel +41 (0) 417 262 080

Fax +41 (0) 417 262 081

info@grip-antislip.com

www.grip-antislip.com

GriP AntiSlip Bathroom is a transparent specialty application, which can be applied on shower trays, bathtubs and other wet areas like bathrooms, swimming pools and wellness centers.

Based on a solvent-free, 2-Component Polyurethane System, the anti-slip coating is environmentally friendly and safe in usage. It can be applied to acrylics, steel-enamel, solid surface, stones, tiles, marble, glass, and other closed surfaces.

GriP AntiSlip Bathroom is the only world-wide certified anti-slip coating.

TÜV Rheinland, Safety Class C, according to DIN 51097

Satra Technology Centre UK, United Kingdom according to BS 7976-2:2002.

CSIRO Infrastructure Technologies - Australia and New Zealand according to EN13 / 2516 03/0212

Warranty: 12 months after delivery.

GriP AntiSlip Bathroom is available in 1.2m2 application kits, which includes coating and necessary application tools.

Contents GriP AntiSlip Bathroom 1.2m2 kit

- Basis Coating "A"
- Hardener "B"
- Primer, "Promoter P"
- Cleaning cloth, pressed
- Application Roller, Roller holder
- Masking tape
- Mixing Stick
- Plastic safety gloves
- Application Manual

Application Manual

1. The surface needs to be free from fat, dirt and needs to be dry. It is possible a pre-application cleaning is necessary with GriP Intensive Cleaner (the surface should not be treated with a nano-coating or other application – no adhesion possible).
2. IMPORTANT: During the complete application and drying process, the surface needs to be kept dry. It should be avoided that water or other fluids affect the coating before drying process is complete.
3. Drop cleaning cloth in GriP AntiSlip® Promoter „P“. Apply Promoter to the surface. Wait 4 to 5 minutes.
4. Wipe the surface dry with a clean (paper)towel or cloth. Friction should be noted when the surface is dry.
5. Surface check: Take a piece of masking tape and apply to the surface. If the tape has good adhesion, so continue to step 6. ! If the tape comes off easy, repeat step 2 till 5..
6. Apply the masking tape to the surface. Mask the edges and if desired additional lines within the area for better water flow. Always mask grouts when tiles are larger than 10cm, to improve adhesion of the coating!
7. Roll a piece of masking tape with the sticky side on the outer side around your hand. Wipe over the roller to clean from possible lint.
8. Open GriP Basecoat „A“ and mix the coating with the mixing stick.
9. Open Hardener „B“ and pour into GriP Basecoat „A“. Mix thoroughly until both components are fully mixed. Make sure to blend in material from the bottom and side of the cup. The mixed coating needs to be applied immediately (within 15 minutes).
10. Pour contents of cup „A“ in polystyrene lid, which functions as a paint tray.
11. Put the roller on the roller holder and drench with coating. Make sure the roller has fully absorbed the coating. Roll off excessive coating in the paint tray.
12. Apply the coating with the roller within the masked area. Make sure to equally spread the coating over the surface. Always start in the middle over the longer side of the surface and distribute equally inwards. Then, continue in transverse direction without applying pressure.
13. Remove the masking tape directly after finishing the application.
14. The surface can be accessed and used after 12 hours drying time. Mechanical- and chemical cleaning of the surface is possible after five days.

Attention!

- Ideal room temperature for the application: 20° Celsius without high air humidity.
- Always turn off floor heating one day in advance of the application process. Floor heating should remain turned off during the drying process.